

# HOW TO: Sleeving a lineset



How to make sleeved loops in your lines using Prism QuickSleeves:

1. Hook the intact loop ends over something fixed (hook, fence post, log) and stretch both lines out to their full length.
2. Cut both lines to the same length with a knife, removing the loop on the unbroken side.
3. Use the thin wire loop inside the QuickSleeves to fish each line through the hollow sleeving. Slide the sleeving off onto each line.
4. With tension on both lines, slide the sleeving to the same position on each side.
5. Holding even tension on both lines, use a permanent marker to put a tic mark across both lines about 1" beyond either end of the sleeving.
6. Fold each line so the tic marks match up, and use two overhand knots in a row to tie loops in the lines and sleeving.
7. Pull evenly on both lines to check that they are the same length within 1/2". Loosen knots and adjust one loop if necessary.
8. Cut off the loose Spectra tail on each loop.

